

Chapter 25 Create Block for Boat

A. Create Rectangle.

Step 1. MAIN MENU.

Step 2. Create.

Step 3. Rectangle.

Step 4. 1 Point.

Step 5. Key-in **9** for Width and **3** for Height, Fig. 1.

Step 6. For the Placement Point, click the bottom left gray rectangle and click OK, Fig. 1.




Fig. 1

Step 7. Origin.

Step 8. Use **ALT-F1** to fit rectangle on the screen.

Step 9. MAIN MENU.




Fig. 2

B. Create 3d Block.

Step 1. Change to the Isometric View. Use **ALT-6 I**. Hold down ALT and press 6. Key-in I.

Step 2. Use **ALT-F1** to fit drawing on the screen.

Step 3. Xform.

Step 4. Translate.

Step 5. All.

Step 6. Entities.

Step 7. Done.

Step 8. Rectangle.

Step 9. Key-in **Z -1.5** and press ENTER.

Step 10. Click Join and OK.

Step 11. Use **ALT-F1** to fit the drawing.




Fig. 3

Fit on Screen ALT-F1	Delete F5	Repaint F3	Zoom In F1	Unzoom Page Down
----------------------	-----------	------------	------------	------------------

Mastercam BLOCK FOR BOAT Page 25-1

Brookside Middle School Tech Ed

<http://www.sarasota.k12.fl.us/brookside/cudacountry> email:cudacountry@comcast.net

Step 12. Click the Clear Screen Colors Tool  in the top tool bar.

C. Save Your File.

Step 1. MAIN MENU.

Step 2. Files.

Step 3. Save.

Step 4. Key-in **boat block** file name and press ENTER.

D. Draw Vertical Back Line.

Step 1. MAIN MENU.

Step 2. Create.

Step 3. Line.

Step 4. Endpoints.

Step 5. Midpoint.

Step 6. Click the top back line, **Fig. 4**.

Step 7. Change the depth of your drawing. Click the Z Button from the Secondary Menu (bottom of the menu) and key-in **-1.5** and press ENTER. (**ALT-0**)

Step 8. Midpoint.

Step 9. Click the bottom back line, **Fig. 4**.




Fig. 4

Continued on Next Page

E. Set Up Levels.

Step 1. MAIN MENU.

Step 2. Display Levels Manager. Use **ALT-Z**.
Hold down ALT and press Z.

Step 3. Press Tab key to move to the Name Field and key-in **Block**.

Step 4. Press Shift-Tab key to backup one field to the Number Field and key-in **2**.




Fig. 5

Step 5. Press Tab key to move to the Name Field and key-in **Geometry**.

F. Create Point.

Step 1. MAIN MENU.

Step 2. Create.

Step 3. Point.

Step 4. Position.

Step 5. Midpoint.

Step 6. Click the bottom front line on the block.

Step 7. Save your drawing. Use **Alt-A** and press ENTER.




Fig. 6