


# CO<sub>2</sub> Shell Car E-Clip



## A. Sketch Circles.

Step 1. Click File Menu > New, click **Part Metric** and OK.

Step 2. Click **Right Plane**  in the Feature Manager and click **Sketch**  on the context toolbar, **Fig. 1**.



**Fig. 1**


Step 3. Click **Circle**  (S) on the Sketch toolbar.

Step 4. Sketch **three circles** coincident at Origin , **Fig. 2**.

Step 5. Click **Smart Dimension**  (S) on the Sketch toolbar.

Step 6. Dimension diameters, **Fig. 2**.

Step 7. Click **Zoom to Fit**  (F) on the View toolbar.



**Fig. 2**

## B. Save as "E CLIP".


Step 1. Click File Menu > Save As.

Step 2. Key-in **E CLIP** for the filename and press ENTER.


## C. Add Centerlines.

Step 1. Click **Centerline**  in the **Line flyout**  on the Sketch toolbar.

Step 2. Starting from the Origin  sketch **two centerlines** out to the middle circle. Keep **one horizontal** and the other at angle, **Fig. 3**. To terminate chain, double click back on the line you have just sketched.

Step 3. Click **Smart Dimension**  (S) on the Sketch toolbar.

Step 4. Dimension angle **70°**, **Fig. 3**.



**Fig. 3**


## D. Trim 1.

Step 1. Click **Trim Entities**  (S) on the Sketch toolbar.

Step 2. In the Trim Property Manger:

select **Trim to closest** ,

**Fig. 4**  
click the **two arcs** to trim, **Fig. 5**  
results shown in **Fig. 6**.




**Fig. 5**

## E. Centerlines.

Step 1. Click **Centerline**  in the **Line flyout**  on the Sketch toolbar.

Step 2. Sketch a vertical centerline from

Origin  up to outside circle. Sketch a second centerline from top endpoint of middle circle at angle to outside circle, **Fig 7**.




**Fig. 6**

Step 3. Click **Smart Dimension**  (S) on the Sketch toolbar.

Step 4. Dimension angle between centerlines **8°**, **Fig. 7**.

Step 5. Save. Use **Ctrl-S**.



**Fig. 7**

## F. Trim 2.

Step 1. Click **Trim Entities**  (S) on the Sketch toolbar.

Step 2. In the Trim Property Manger:

select **Trim to closest** , Fig. 8  
click arcs to trim, Fig. 9  
results shown in Fig. 10.




Fig. 9




Fig. 10




Fig. 8

## G. Add Lines.

Step 1. Click **Line**  (L) on the Sketch toolbar.

Step 2. Sketch **three lines** between arcs, Fig. 11.

Step 3. Save. Use **Ctrl-S**.




Fig. 11

## H. Sketch Fillets.

Step 1. Click **Sketch Fillet**  on the Sketch toolbar.

Step 2. In the Sketch Fillet Property Manager set:  
under Fillet Parameters, **Fig. 12**

**Radius**  **.3**  
click **top two corners**, **Fig. 13**  
click OK 

**Radius**  **.35**, **Fig. 14**  
click **bottom corner**, **Fig. 15**  
click OK  twice.




Fig. 13



Fig. 12




Fig. 15




Fig. 16





Fig. 14

## I. Mirror.

Step 1. **Right click** an arc of the sketch and click **Select Chain** from the menu, **Fig. 17**.

Step 2. **Ctrl-click** vertical centerlines to add to selection, **Fig. 18**.

Step 3. Click **Mirror Entities**  on the Sketch toolbar, **Fig. 19**.

Step 4. Save. Use **Ctrl-S**.




Fig. 17




Fig. 18





Fig. 19

## J. Extrude.

Step 1. Click **Features**  on the Command Manager toolbar.

Step 2. Click **Extruded Boss/Base**  on the Features toolbar.

Step 3. In the Property Manager set:  
 under Direction 1, **Fig. 20**  
 End Condition **Mid Plane**  
 Depth  **.25**  
 click OK .




Fig. 21





Fig. 20

## K. Mate Reference.

Step 1. Click a **cylindrical face** to select it, **Fig. 22**.

Step 2. Click **Reference Geometry**  on the Features toolbar and **Mate Reference** from the menu.

Step 3. In the Mate Reference Property Manager click OK , **Fig. 23**.




Fig. 22




Fig. 23

## L. Material Stainless Steel.

Step 1. **Right click** **Material**  in the Feature Manager and click **Edit Material**.

Step 2. Expand **Steel** in the material tree and select **AISI 316 Stainless Steel Sheet**. Click **Apply** and **Close**.

Step 3. Save. Use **Ctrl-S**.




Fig. 24